

图 1

# PocketWizard

## Update

### Firmware

Check For Updates

<- These functions are used to update the firmware on your device.

Update Firmware

Factory Reset

# 软件首页



Advanced Mode

Help



### Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

#### Check For Updates

Looks online for new versions of the PocketWizard Utility and new versions of firmware for the connected radio, as well as radios you've previously connected. A dialog box will pop up with additional instructions if required.

#### Update Firmware

Updates or re-installs the firmware in a connected radio. If this button is grayed out, then no radio is connected. Connect a radio via USB to update or re-install its firmware.

#### Factory Reset

Resets the connected radio to Factory Defaults. All settings will be lost unless you saved them.

Utility Settings

图 2

# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000479 Connected

Model: CE - Europe  
 Application Version - 2 (build 50)  
 Loader Version - 2 (build 7)  
 Hardware Version - 104-102



按Update进入更新画面

Update

Settings

Configuration C1

Configuration C2

Channel

Misc

## Transmit

ControlTL Transmit Channel 1 Using ControlTL Channel 1

Standard Transmit Channel 1 Using Standard Channel 1

## Receive

Use ControlTL for Receive Channel

ControlTL Receive Channel 1 Using ControlTL Channel 1

Standard Receive Channel 32 Using Standard Channel 1

接上了普威后的画面

Apply Changes

Replicate

Save Profile

Load Profile


 Advanced Mode

Help



PocketWizard Utility Context Help Win...

Channel Tab

Set the PocketWizard channels in use. Make sure to set all radios to the same channel(s). ControlTL and Standard channels do not need to be the same. Mix and match as it suits your situation.

Settings are not stored in your radio until the Apply Changes button is pressed!

Make sure to choose a set of channels that will not interfere with other PocketWizard users.

### Transmit Channels

A MiniTT1 or FlexTT5 radio transmits on both a ControlTL channel and a Standard channel. At shutter speeds using High Speed Sync (HSS/FP), only ControlTL triggers are sent.

ControlTL Channels are for triggering remote FlexTT5 radios or other ControlTL radios with PowerTracking. Standard Channels are for triggering the Plus II, MultiMAX, or any PocketWizard performing simple triggering without TTL or PowerTracking. ControlTL and Standard channels do not need to be the same. Mix and match as it suits your situation.

Defaults = Channel 1 for Configuration C1 and Channel 2 for Configuration C2.

# 图 3

# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000479 Connected

Model: CE - Europe  
Application Version - 2 (build 50)  
Loader Version - 2 (build 7)  
Hardware Version - 104-102



按 Check For Updates 进入  
检查更新

Update

Settings

## Firmware

Check For Updates

<- These functions are used to update the firmware on your device.

Update Firmware

Factory Reset



Advanced Mode

Help



### Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

### Check For Updates

Looks online for new versions of the PocketWizard Utility and new versions of firmware for the connected radio, as well as radios you've previously connected. A dialog box will pop up with additional instructions if required.

### Update Firmware

Updates or re-installs the firmware in a connected radio. If this button is grayed out, then no radio is connected. Connect a radio via USB to update or re-install its firmware.

### Factory Reset

Resets the connected radio to Factory Defaults. All settings will be lost unless you saved them.

Utility Settings

# 图 4

# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000479 Connected

Model: CE - Europe  
Application Version - 2 (build 50)  
Loader Version - 2 (build 7)  
Hardware Version - 104-102



按 Download Now 下载

**Firmware Updates Available**

These are all the firmware versions available for your registered Units. If you would like to download firmware to your computer to see if your Unit needs updating, click the Download Now button. This will only download the firmware, you will be prompted later to install it on your Unit.

Version Selection

- MultiMAX CE Firmware Version 7.50 - Official Release.
- MiniTT1 Canon CE Firmware Version 5.200 - Official Release
- MiniTT1 Canon FCC/US Firmware Version 5.200 - Official Release
- FlexTT5 Canon CE Firmware Version 5.200 - Official Release
- FlexTT5 Nikon CE Firmware Version 2 (Build 100) - Official Release

Download ALL files

Download Now Cancel

会自动勾选适合的固件

### Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

## Update Settings

### Firmware

Check For Updates

Update Firmware

Factory Reset

Advanced Mode

Help

Utility Settings

updates

... for new versions of the  
... rd Utility and new versions of  
... the connected radio, as well  
... u've previously connected. A  
... will pop up with additional  
... if required.

ware

... e-installs the firmware in a  
... radio. If this button is grayed  
... radio is connected. Connect  
... USB to update or re-install its

Resets the connected radio to Factory Defaults. All settings will be lost unless you saved them.

图5

# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000479 Connected

Model: CE - Europe  
Application Version - 2 (build 50)  
Loader Version - 2 (build 7)  
Hardware Version - 104-102



按OK

Update Settings

## Firmware

Check For Updates

<- These functions update the firmware

Update Firmware

Factory Reset

**Update Unit**

This will update the firmware in your Unit.

Your current settings will be automatically saved, but may not be able to be reloaded depending on the differences between the firmware versions. If you wish to reuse your settings, press Cancel and manually record your settings before starting the firmware update.

Press OK to start the firmware update.

Please wait for the update to complete.

Do not connect or disconnect any Units during the update.

OK Cancel

PocketWizard Utility Context Help Win...

### Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

### Check For Updates

Looks online for new versions of the PocketWizard Utility and new versions of firmware for the connected radio, as well as radios you've previously connected. A dialog box will pop up with additional instructions if required.

### Update Firmware

Updates or re-installs the firmware in a connected radio. If this button is grayed out then no radio is connected. Connect radio via USB to update or re-install its firmware.

### Factory Reset

Resets the connected radio to Factory Defaults. All settings will be lost unless you saved them.

### Utility Settings

Advanced Mode

Help

# 图 6

# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000479 Connected

Model: CE - Europe  
Application Version - 2 (build 50)  
Loader Version - 2 (build 7)  
Hardware Version - 104-102



0%

Overall Progress

0%

Validating File

Update

Settings

按 Yes

Configuration C1

Configuration C2

Channel

Misc

Transmit

ControlTL Transmit Channel 1

Standard Transmit Channel 1

Receive

Use ControlTL for Receive Channel

ControlTL Receive Channel 1 Using ControlTL Channel 1

Standard Receive Channel 32 Using Standard Channel 1

Apply Changes

Replicate

Save Profile

Load Profile



Advanced Mode

Validating Application Files...

Help



PocketWizard Utility Context Help Win...

[www.PocketWizard.com](http://www.PocketWizard.com)

Click on the PocketWizard logo to visit [www.PocketWizard.com](http://www.PocketWizard.com)

### Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

### Check For Updates

Looks online for new versions of the PocketWizard Utility and new versions of firmware for the connected radio, as well as radios you've previously connected. A dialog box will pop up with additional instructions if required.

### Update Firmware

Updates or re-installs the firmware in a connected radio. If this button is grayed out, then no radio is connected. Connect a radio via USB to update or re-install its firmware.

### Factory Reset

Resets the connected radio to Factory

图 7

# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000479 Connected (Loader Running)

Model: CE - Europe  
Application Version - 2 (build 50)  
Loader Version - 2 (build 7)  
Hardware Version - 104-102



Overall Progress



Programming Application

## Update

### Firmware

Check For Updates

<- These functions are used to update the firmware on your device.

Update Firmware

Factory Reset

更新中, 请勿断开连线.

Updating Unit Firmware To Version 2.100...

**Do Not Disconnect while Unit is being updated**



Advanced Mode

Help



[www.PocketWizard.com](http://www.PocketWizard.com)

Click on the PocketWizard logo to visit [www.PocketWizard.com](http://www.PocketWizard.com)

### Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

### Check For Updates

Looks online for new versions of the PocketWizard Utility and new versions of firmware for the connected radio, as well as radios you've previously connected. A dialog box will pop up with additional instructions if required.

### Update Firmware

Updates or re-installs the firmware in a connected radio. If this button is grayed out, then no radio is connected. Connect a radio via USB to update or re-install its firmware.

### Factory Reset

Resets the connected radio to Factory



# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000479 Connected

Model: CE - Europe  
Application Version - 2 (build 100)  
Loader Version - 2 (build 7)  
Hardware Version - 104-102



**Update** Settings

按Yes

Configuration C1

Configuration C2

会自动还原上次储存了更改的设定。

Channel Misc

### Transmit

ControlTL Transmit Channel

Standard Transmit Channel

### Receive

Use ControlTL for Receive Channel

ControlTL Receive Channel 1

Using ControlTL Channel 1

Standard Receive Channel 32

Using Standard Channel 1

Apply Changes

Replicate

Save Profile

Load Profile

Advanced Mode

Help

PocketWizard Utility Context Help Win...

[www.PocketWizard.com](http://www.PocketWizard.com)

Click on the PocketWizard logo to visit [www.PocketWizard.com](http://www.PocketWizard.com)

### Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

### Check For Updates

Checks online for new versions of the PocketWizard Utility and new versions of firmware for the connected radio, as well as radios you've previously connected. A dialog box will pop up with additional instructions if required.

### Update Firmware

Updates or re-installs the firmware in a connected radio. If this button is grayed out, then no radio is connected. Connect a radio via USB to update or re-install its firmware.

### Factory Reset

Resets the connected radio to Factory

**PocketWizard Utility**

The Firmware Update for Unit 5NC000479 has been successfully programmed and a factory reset was performed.  
Your previous settings are saved in file TT5N 5NC000479 2011-04-06 112511.dat, in directory C:/Documents and Settings/SellenHK/PocketWizard Utility Profiles/TT5N

Reload saved settings?

Yes No

按No会跳去图10  
告示对话视窗。



图 9

# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000689 Connected

Model: CE - Europe  
 Application Version - 2 (build 100)  
 Loader Version - 2 (build 7)  
 Hardware Version - 104-102



**Update** **Settings**

**Configuration C1**

**Configuration C2**

**Channel**

**Misc**

### Transmit

ControlTL Transmit Channel 1 Using ControlTL Channel 1

Standard Transmit Channel 1 Using Standard Channel 1

### Receive

Use ControlTL for Receive Channel

ControlTL Receive Channel 1 Using ControlTL Channel 1

Standard Receive Channel 32 Using Standard Channel 1

## 完成固件更新

Apply Changes Replicate Save Profile Load Profile

Advanced Mode

Help

PocketWizard Utility Context Help Win...

[www.PocketWizard.com](http://www.PocketWizard.com)

Click on the PocketWizard logo to visit [www.PocketWizard.com](http://www.PocketWizard.com)

### Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

### Check For Updates

Looks online for new versions of the PocketWizard Utility and new versions of firmware for the connected radio, as well as radios you've previously connected. A dialog box will pop up with additional instructions if required.

### Update Firmware

Updates or re-installs the firmware in a connected radio. If this button is grayed out, then no radio is connected. Connect a radio via USB to update or re-install its firmware.

### Factory Reset

Resets the connected radio to Factory

# 图 10

# PocketWizard

PocketWizard FlexTT5 - Unit 5NC000689 Connected

Model: CE - Europe  
Application Version - 2 (build 100)  
Loader Version - 2 (build 7)  
Hardware Version - 104-102



按OK后会去图9  
的完成画面。

Update Settings

Configuration C1

Configuration C2

Channel Misc

Transmit

ControlTL Transmit Channel

Standard Transmit Channel 1

Receive

Use ControlTL for Receive Channel

ControlTL Receive Channel 1 Using ControlTL Channel 1

Standard Receive Channel 32 Using Standard Channel 1

**PocketWizard Utility**

**档案名称**

Radio programmed at Factory Default.  
Your previous settings are saved in file TT5N\_5NC000689\_2011-04-06\_112908.dat, in directory C:/Documents and Settings/SellenHK/PocketWizard Utility Profiles/TT5N.  
Press the Load Profile button to restore the settings from the backup file.

OK

告知可按下面Load Profile可  
还原上次已储存更改的设定。

Apply Changes Replicate Save Profile Load Profile

Advanced Mode

Help

PocketWizard Utility Context Help Win...

[www.PocketWizard.com](http://www.PocketWizard.com)

Click on the PocketWizard logo to visit [www.PocketWizard.com](http://www.PocketWizard.com)

Update Tab

Update firmware or the Utility program, or perform a Factory Reset.

Check For Updates

Check online for new versions of the PocketWizard Utility and new versions of firmware for the connected radio, as well as radios you've previously connected. A dialog box will pop up with additional instructions if required.

Update Firmware

Updates or re-installs the firmware in a connected radio. If this button is grayed out, then no radio is connected. Connect a radio via USB to update or re-install its firmware.

Factory Reset

Resets the connected radio to Factory